Check your pen and printer

A4 / Actual size / 100% / Colour laser / 600 dpi or higher

Turn off fit-to-page, borderless enlargement, draft and toner saving.

Measure the 50 mm ruler below. If it is a different length, correct the print scale.

With the pen disconnected, draw a small circle inside each of the five targets.

Then collect in the iPhone app. Check that writing from all five targets appears.

1

2

3

4

5

This checks this pen and this print. Repeat after changing printer or settings.